

Upgrade Guide

Firstly, exit the driver and make sure that the keyboard is under the wired mode.

NOTE: Only ONE upgrading toolbox can opened in one time, otherwise the upgrading process fails.

If the upgrading process fails, the cable must be disconnected. Open the upgrading toolbox and reconnect the keyboard by the cable again, the tool will upgrade the dead keyboard automatically.

Click the following places to upgrade your keyboard:

